


Installation Manual for Slide Out Fan Kit

Take the top side vent off and mount the fan on the inside of the vent using the supplied zip ties. You want to make sure the arrow on the front of the fan is pointing down into the opening of the air louver.



Picture below is an outside view of how the fan gets mounted.



To hook up the wiring, take the black wire from the fan, with the ground ring terminal, and attach it to one of the screws that hold the thermostat to the cooling unit. Then take the red wire from the fan, with the piggyback connector, and plug it into the side of the thermostat where the lower ventilation fans are hooked to. Plug the red wire from the lower vent fans into the piggy back spade. Note: Make sure that you don't plug the piggy back connector into the side of the thermostat with your constant 12V source so that the fan doesn't run continuously.

