HVAC 120V Cooling Unit for Models:

682, 683, 483, 482, 8682, 8683, 6082, 6083, 6182, 6183, 982, 9182, 983, 9183, 810, 841, 821, 822, 811, 843, 1095, 962, 9162, 963, 9163, 941, 643, 641, 621, 611, 610, 462, 463, 662, 663, 862, 863, 6162, 6163, 6062, 6063, N600 With universal controller

JC REFRIGERATION INSTALLATION MANUAL



Jr-Jeremy & Aaron Lambright

INFO@JC-REFRIGERATION.COM www.jc-refrigeration.com



Good Day Friends, this is how it all begins, hope you find this helpful thru your installation.



And enough time to think things thru at times, so don't give up and hang in there to the end it will be all worth it. A cold fridge is about to be had!!



We at JC Refrigeration try to build these cooling units so that the install is as easy as possible. Making them DIY friendly. But please be aware though, that our upgrades might not look quite the same as the original. The brackets, frames, and holes in the plates might not always line up perfectly as fridge boxes can vary at times. So, some modifications, such as shaving the foam or tweaking the cooling unit, might need to be done to complete the installation. But keep in mind, these cooling units are made out of thick steel tubes and plates so if some minor tweaking or bending is needed, you can do that without harming the cooling unit. We try to be as thorough with our install manuals as possible, but if you need help with something during the install, feel free to send us an email at info@jc-refrigeration.com with your question, along with a picture to help explain what you are facing, and we will help you to the best of our ability.

JR & Jeremy Lambright

Please read through these notes before starting:

- Throughout this manual, there will times when you see (RA), (YA), or (BA). These are referring to red arrow, yellow arrow, and blue arrow. We use these to point to a certain spot or part in the pictures.
- There are some differences between this install manual and the install videos on our website. So, to avoid confusion, follow <u>only</u> the instructions in this manual.
- This unit is for 120V AC hook up only so most times this will be plugged into inverter power so it can run while travelling, if a new power wire needs to be run the best time to do this is when the fridge is out of the cavity
- Remember your old rear or front control boards will no longer be used, they can be taken completely out or just left in and not used. Same with wires and fans, what you take off will no longer be used but can be saved for future use if needed or discarded.

PLEASE NOTE: Not all of our cooling units look exactly the same. So, to avoid confusion, only follow the instructions in this manual when installing the unit.

To start this process, begin by taking the cooling unit out of the box, if box appears to be damaged don't panic as we foam package them into the box (YA) and so the box can be practically destroyed and the unit is still not damaged. So, when you take the box apart you will notice a spray foam packing inside and this needs to be removed and then the unit will slide out. Inside the box you should have the cooling unit, and parts needed to do the install (RA)





Begin by covering up your floor with blankets and removing any door handles or smoke alarms that might hinder the exit of your refrigerator from your cabinet. Turn off the water pump (if you have an ice maker in your fridge) and the refrigerator control panel.



Make sure to turn off LP gas at the tank before starting the install.



Locate your refrigerator side vent on the outside of your RV.Take the main 12V wires (RA) loose from your board. The wire colors will vary from coach to coach, and there is an old style or new style as seen.



Note: If your

Ν

wire ends are not insulated, wrap the end in electrical tape on positive so you don't blow the fuse.

Unplug your 120v plug (RA) from your RV receptacle. Take the LP line (YA) off of the LP solenoid valve. Make sure gas is turned off (see step one)



Cap off the LP line with the supplied cap in the parts bag (RA). Check this joint with soap and water once gas has been turned back on.



There are many different styles out there but most have at least 2 mounting screws through the back plate holding the fridge to your RV floor. Screw size and bit needed will vary from coach to coach.

Remove these screws or Bolts (RA).



On Winnabago coachs you will have 4 bolts lagged to a steel side plate, 2 on each side of the fridge, also the top roof vent cap needs to be removed and 2 to 4 philips screws need to be loosend from the top of the fridge.



Going inside again start by removing the black trim covers on the top and bottom.

Remove the two mounting screws on top and bottom (RA). Screw size and bit needed will vary from coach to coach.





Take a 5/16" hex bit and cordless impact driver and proceed to loosen all the screws (RA) in the freezer and the refrigerator. Unclip thermistor and leave it hanging down into the fridge box. Removing your freezer shelve or top fridge shelve is optional.



We do not show the fridge being slid out onto the floor, as the lay out of the coaches vary greatly and so it could be misleading to your scenario. But the object is to have 1 guy on each side of the fridge and as your fridge starts to exit lift up gently so when the rear end of the fridge fully exits the cavity that it does not drop, but needs to be gently and carefully set on the floor and pushed or carried to your open floor area. Lay fridge face down on the floor, making sure doors are latched shut so they don't swing open and we normally put a pile of blankets on the floor by the top freezer door so the fridge is lying face down on an angle.



Take out mounting screw (RA) on top, Placement can vary

Remove bottom 2 mounting screws, may vary in location (RA).





Take off the 2 white LP valve wires (RA).

Unclip the igniter wire (RA) from the board.





Take the 120v plug (YA) loose from the board in order to remove the cover.

Remove the board cover and then remove the heating element wires. (RA)



Remove the 120V power cord completely as it will no longer be needed. Also, remove the green board ground wire.



Also remove the gas valve mounting screws, and the defrost cup keep the cup for later use.





Take unit off the cooling unit of your refrigerator by lifting straight up and out.

Clean off the old thermal mastic (RA) from the freezer section and the fin section. A large blade putty knife or scraper works well.



Insert the controller into the fridge box through the fins as shown in the picture below. Lift the right-hand side of the fins and insert the controller inside, clip to the shelf for now so it does not get damaged till you are ready to attach to the fin. Make sure and leave enough wire so it will can be mounted anywhere on the fin. But check to make sure you still have enough wire on the outside so it will reach to the compressors.



Warning: The next few steps are very important. If done incorrectly, the cooling unit freezer and fin screws might not line up the best. If possible, have someone to help you with the next steps as it will make everything much easier.

First, we will do a "dry run". Set the unit in the box as shown in picture.



If you are alone, screw two self-drilling #10X1" mounting screws (RA) that are included in the parts bag. Your exterior mounting holes will not line up to the original holes. This will hold the unit in place for the next step. If you have another person with you leave these screws out and have the second person hold the unit while you set the refrigerator upright into the standing position now open freezer door and make sure mounting holes in the freezer are aligned with the cooling unit holes.



If holes are not aligned have the rear person lift the unit up or down or side to side till holes are aligned, or if alone you have to set fridge back down, take out mounting screws and adjust the unit to where the holes line up. It does not have to be perfect, just close enough where you can see the edge of the screws. Don't be afraid to sand or shave foam off the side, top or bottom to let the unit slide the way it needs to go to line up the freezer screws. Pictured below is an example with the holes just visible on the bottom corner (RA)

Warning: Your box holes can be redrilled or enlarged to make holes line up and then the washers can cover the hole, (YA) <u>but do not ever drill new holes</u> into the cooling unit plates as you will hit the cooling tubes causing a rupture. If part of holes are visible you can either leave them as is since unit will be sealed in the back or you can use white silicone caulk to cover the holes.



Once you have positioned the unit to where your holes align with your freezer holes, re-enter the previous mounting screws shown in picture below (RA). This way you know exactly where the unit needs to be later. If a second person is there to help these screws do not have to be put back in.



Take the unit completely off the box again. We will install the thermal mastic next. Take a caulk gun and place a small bead in this fashion. You will need to use the whole tube.



Lay unit back into box being careful so as not to scrape off any thermal mastic on the box, and make sure unit is in position where you had it last so freezer holes line up. Now screw the unit to the back of the fridge using the #10X1"selfdrilling hex screws provided



Your controller wire will exit on the bottom of the foam insert between unit and box. (YA)



Set the refrigerator upright into the standing position and install all 8 freezer screws, using the supplied #10X2"screws in the parts bag, pulling the unit tight against the back.



The fins in the fridge will now only have the 2 middle screws attached instead of 4 like the original had. The thermistor can be clipped back to the fin but it will not be used



The thermistor can be clipped back onto the fins, but this will no longer be used. Clip your controller onto the fin close to center left/right



Warning: Make sure this step gets followed precisely, otherwise your fridge is unable to cool properly

Lay fridge back down, take the can of Great Stuff foam (shake can for a few seconds) and apply a bead of foam around all four sides as shown below. Make sure and seal all cracks and gaps. This will help seal all air leaks while travelling down the road.



On areas where the steel frame is tight against the box, take a small pry bar or flat bar and lift up enough to get in there to fill up the gap between unit and fridge box. Make doubel sure all gaps and cracks are sealed off, very important!!



After filling all gaps with foam, follow up with the supplied aluminum tape as shown. This is for cosmetic looks only; this tape does not help seal.



120V Hvac Universal Controller installation

This controller eliminates all of your existing Dometic controls. So that means that your front display panel, your interior light, and your rear control board will no longer work and can be taken out if need be. This new controller has its own on/off switch, temp control thermostat, as well as a light bulb that is motion activated. Long Life roller bearing fans to give you frost free satisfaction for years to come



Included in Package:

- 1- Control Assembly (Pic above)
- 2- Compressor Relay control (pic below) will be zip tied to the unit





2-3-slot wago

Installation

Make sure controller is set to "Off" before starting the install.

<u>Step 1:</u> If you have an existing fin fan on your fins unclip those and move them towards the left so you have room to clip this new controller onto the right side of the fin. The existing fin fan wires can be twisted in with the new control wires and inserted into the wago. Shown later

Step 2: Strip about 6 inches of the white coating off of the end of the wire. Inside there will be 4 smaller wires, red, black, green and white.



Step 3: Strip about ¼ inch off the end of each wire.



Step 4: The white wire connects to the red wire from the relay control box (WA) The green wire connects to the black wire from the relay control box **(GA)** The Red/Black wires coming from the inside controller will be hooked up later



Step 5: Attach the relay box to the back of the unit or fridge box to your preference. Or it can simply just be attached to the floor board of the coach later.

Now is a good time to zip tie all loose wiring and defrost hose into place, also a good time to inspect the fridge cavity to make sure it's clean. Fridge can now be stood up to get ready to insert into the cavity. You can attach the drain tube to the copper line with cable ties to hold it in place. Most of these models will drain out of the side vent , if you are using the defrost cup slide it(RA)back under copper tube and attach with one of the #10X1" self drilling screws or this defrost cup can be left off and the hose stuck out the side vent when all done.



Warning: Please make sure and follow this thru this step, otherwise unit could over heat causing damage to the unit.

Before installing the fridge back into the cavity, check to make sure wall insulation is secured and this is a good time to sweep or vacuum any loose debris. If this fridge is installed into a slide out then make sure and remove the top side vent (YA) baffling (RA), as you will no longer need this and all it will do is slow air flow. If it's installed into a roof vent style then nothing has to be changed, but make sure and leave both vents open, as this unit will still have to breathe



Now you're ready to slide the refrigerator back into the cavity. Once it's started it helps to have someone outside to watch as you slowly push the fridge back into place, making sure the gas line is out of the way. Install mounting screws (RA)on the top and bottom first before finishing outside.





Attach black trim pieces on top and bottom.

Now we are ready to finish the outside. Put the two mounting screws (RA) back in place.



WARNING: Make sure this gas plug has been checked for leaks (RA) this copper tube can be bent carefully and tucked out of the way once the fridge is back in place



<u>Step 6:</u> Now find your 12V DC wires coming from your coach batteries. Which will be powering your inside universal control. The pic below shows these wires being blue/white from the coach, but these can be any color or size, (dependent on the coach manufacture)



Step 6A The 12V DC wires on most coaches come up through the floor behind the fridge, make sure to not get these 2 together as this will blow your 12V fuse. Make sure you know which one is positive.

Step 7 Take the small red/black wire from the inside controller and add the 3slot wago to each one Then make sure you know which is the 12V + wire from the batteries and connect it into the red wire from the controller using one of the 3slot wago included. Next take the black wire from the controller and connect to the negative from your battery using the other 3-slot wago included. This is where you add your existing fin fan if you have one, red to red black to black.





Now plug your 120V cord from the relay box into the outlet behind the fridge.

We highly recommend using a digital wireless thermometer to monitor your inside fridge temps, many phone calls or temp misleading's can be avoided by making sure the thermometers you are using are accurate. You do not have to use our brand but we do recommend using something similar to this type.

https://jc-refrigeration.com/product/refrigerator-freezer-digital-wireless-thermometer-free-shipping/

Use digital wireless

DO NOT USE





Clip the sensor for the fridge on the bottom side of the first shelf beneath the fin, place it so the sensor is centered, front to back and side to side (RA), if its clipped underneath it will be out of the way and shouldn't interfere with storage.



The same applies the with freezer. Clip the sensor underneath the shelf, centered from side to side, but have this one more towards the back of the freezer.



Operating the Controller:



The switch on the front is to turn your fridge on or off. Once you flip the switch to the on position to turn on the fridge, the temp controller will light up, the fans will turn on and the light will turn on as the motion sensor will detect your movement. (After 30 seconds of no movement, the motion sensor will shut the light off.) The blue number (bottom) on the temp controller is what the temp is set to and the red number (top) is the actual temp inside the fridge. The temp is preset to 34 degrees but you can adjust it up or down using the directions on the next page. After you have the temp controller set to your desired settings, there is nothing more you need to do as this controller will tell the compressor when to turn on or off. If you are using another temp sensor, just be aware the controller temp and your other source of temp reading might not always be the same, and this is ok, just rely on the temp sensor read out you are used to, but make sure yours is either digital wired or wireless.

Hvac Universal Controller Introduction

This controller eliminates all of your existing Dometic controls. So that means that your front display panel, your interior light, and your rear control board will no longer work and can be taken out if need be. This new controller has its own on/off switch, temp control thermostat, as well as a light bulb that is motion activated. Long Life roller bearing fans to give you frost free satisfaction for years to come



Low Ambient Heat Lamp:

On the back side of the control assembly there is a little switch. By flipping this switch to the up position, it bypasses the motion sensor and keeps the light bulb turned on constantly. If you are using your fridge in cold weather (Usually 40 F or lower), your compressor doesn't have to run very long in order to cool the fridge box down and this will cause the freezer to only stay around 25-30 degrees. Turning the light bulb on constantly will give off a little bit of heat into the fridge box which will cause the compressor to run longer and bring your freezer temp down to 0 to 10 degrees. Once the weather warms up or you move to a warmer climate, flip this switch back to the down position so that the light bulb is motion activated again. If this switch is in the up position while you are in warm/hot weather, you will cause the compressor to run longer and work harder than it needs to.





Set Temp

Press "SET" (top button) briefly, bottom blue number starts flashing. While it is flashing you can adjust temp up using top (SET) button or down using bottom (*C/*F) button.

Enter Diagnostic and Mode settings: We highly recommend not changing any codes unless it's absolutely required, as this can change other things as well. Press and hold top (SET) button for approx. 4 seconds. P0 will flash first. You can then scroll through code settings using (SET) button to the setting needed. Once the desired code is reached, press both (SET)(*C/*F) buttons in at the same time, then the bottom blue letter or number will start to flash. Then use top or bottom button to adjust up or down in order to achieve desired setting. Once reaching desired setting, press both the (SET) button and the (*C/*F) button at the same time and the setting will be saved.

Code meaning:

P0 = Lets you switch between heating (H) or cooling (C). You want to make sure it is set to cooling (C)

P1 = This setting determines how far above the set temp the actual temp in the fridge can rise to before the compressor turns on, preset for 2.5

P2= Not needed or used

P3 = Not needed or used

P4 = If actual temp inside the fridge box does not match the top number on the thermostat, this setting can be used to calibrate up or down to make the thermostat temp match your actual box temp. This setting rarely needs adjusting. (Note: One number adjusts the actual calibration by 2 degrees. So if you set it to 1, the actual temp will be calibrated 2 degrees warmer.)

P5 = This setting can be used to set a delay for turning on the compressor. This setting should not need to be adjusted.

P6 = This setting can be used to set a high temp alarm.

P7 = This setting is used to switch between Celsius (CH) or Fahrenheit (FH). It is preset to Fahrenheit.

P8 = This setting can be used to reset the controller to factory settings. Not recommended to use this setting.

To do a diagnostic test if cooling questions arise use chart below to do a direct wire with the compressor in question.

Step 1: Unplug the 120V cord from the outlet. Open tab on the wago to the wire that goes to the small controller. Leave the wire going to the compressor and fan wire intact.



Step 2: Make a 120V pigtail and plug the wires into the empty slot on the Wago where the red and black wires used to be. Then plug the pigtail into a 120V outlet. The cooling unit will now run continuously until the cord is unplugged or the power to the outlet is cut. Make sure vent fan, and compressor runs when power is plugged in.



FAQs

How much will the compressor actually run?

From our testing in 80 degrees, with the fridge and freezer empty, and the doors remaining closed for a 24-hour period, the 120V AC compressor will run approx. 56% of the time and the 12V DC compressor runs approx. 67% of the time. However, keep in mind that this can be very easily affected by a number of variables such as ambient temp, how often the doors are opened, and how much food is in the fridge/freezer.

What is covered under warranty?

Our warranty covers the cooling unit and any of our controls that came with the cooling unit. It does not cover any original Norcold parts such as the control board, the front display, thermistor, etc.

What if the cooling unit needs to be worked on and I'm not close to your location (Shipshewana, IN)?

Contact us first and we will try to help you get the issue resolved. Most problems can be fixed by us through email or phone but if more work, or hands on work is needed, we have a list of dealers/service centers in almost every state that have purchased cooling units from us before and could possibly help you out.

Is there any regular maintenance to perform on these cooling units?

The only thing that needs to be done on these cooling units is to take compressed air and blow any dust or debris out of the condenser fin. This can be done maybe once or twice per year.

